

CHAIN SLING TYPE NAMING CODE

Basic chain sling configurations are often described using a code. Naming conventions has many exceptions and may vary among manufacturers.

1. First Letter often designates the number of legs or branches:

- S** — Single leg with one branch
- D** — Double leg with two branches
- T** — Triple leg with three branches
- Q** — Quadruple leg sling with four branches

2. Second letter normally designates the fitting at the top of the sling:

- O** — Oblong shaped master link
- S** — Sling hook
- G** — Grab hook
- B** — Basket with oblong master sling

3. Third letter or group of letters normally designates the fitting at the bottom of each branch. A few of the many possibilities are listed below.

- S** — Sling hook
- G** — Grab hook
- LK** — Sliding choker
- BK** — Safety hook
- F** — Foundry hook

If **A** precedes the group of letters, then a device to adjust the length has been added. Adjusters can be either of two styles, Type A or Type B. Both are pictured.

Example:

ADOS describes an **A**adjustable, **D**ouble Leg Sling with **O**blong master link on top and a **S**ling hook at the bottom of each leg or branch.




SG



SOS



SOG



SOF



SOBK



SGG




SSS




SSG




ASOS




SOLK




DOS



DOG




DOF




DOBK



DOO




BS




ADOS



DOLK




TOS




TOG



TOF



TOBK



ATOS



QOS




QOG



QOF




QOBK



ENDLESS




AQOS



BD



TYPE A
ADJUSTER



TYPE B
ADJUSTER